

Alert Level: Advisory

Software Version: N/A

Instrument: MMP

Subject: Crate modification to support MMP motor and spring

**Summary:** To prevent the MMP motor from moving during shipment, additional supports have been added inside the MMP Crate. Do not discard any of the material inside the shipping crate. If a crate is being used to ship the MMP that does not have the added stabilization, use foam or other padding to support the motor in a similar manner.

**Potential Negative Effects:** Long-term storage may deform motor bracket.

**Technical Details:** The foam supports the motor from below and the plastic tywrap supports from above (as shown in the photo). This support will minimize potential motor spring damage during shipping due to resonant vibration of the motor and spring.

