

Alert Level: **ADVISORY**

Software Version: MMP 3.10 through 3.14

Instrument: MMP

Subject: Offloading Deployment Data

Summary: In the MMP firmware, the option <D> Deployment in Offload Deployment Data, cannot be used to offload a full deployment. Only a single profile, a range of profiles not more than 2 full profiles, or 9 ENG, ACM, or CTD files (i.e. a total of 9 files) can be offloaded.

Technical Details: If the option <D> Deployment is selected to offload the entire deployment, the system opens too many files and the watchdog will eventually reboot the electronics.

Important: This does not affect the data output of the MMP Unpacker.

Resolution: To avoid this error, offload less than 9 files and then reboot the electronics or use the MMP Unpacker to unpack deployment data. Firmware release version 3.15 corrects this issue.

```
McLane Research Laboratories, USA
McLane Moored Profiler
Version: MMP-3_16.c S/N: ML00000-00C

Main Menu
Thu Mar 30 07:16:28 2006

<1> Set Time           <5> Bench Test
<2> Diagnostics       <6> Deploy Profiler
<3> Flash Card Ops    <7> Offload Deployment Data
<4> Sleep             <8> Contacting McLane
<C> Configure

Selection ? 7

Serial Dump Files From FLASH
Thu Mar 30 07:16:36 2006
Stream serial data from:
  <D> Deployment
  <S> Single profile
  <R> Range of profiles

  <L> Logging files

Exit to:
  <M> Main menu

Selection ?
```

Figure 1: <7> Offload Deployment Data Option