

Alert Level: **INFORMATIONAL**

Software Version: N/A

Instrument: WTS-LV

Subject: New Bulkhead Connector Style

**Summary:** A new WTS-LV bulkhead connector requires less insertion and removal force.

**Details:** An easier to use WTS-LV bulkhead connector requires less force to connect which reduces the risk of damaging connector pins.



*Figure 1: Align and Screw-On WTS-LV Bulkhead Connector*

To join the connector with the bulkhead, align the connector with the notch and screw on as shown in Figure 1. It is unnecessary to push the connector on with force.

Screw on the protective cover for shipment and storage as shown in Figure 2.



*Figure 2: Screw on the Protective Cap*