



Technical Support Bulletin 2009-06

Sampler Water Flush Filters

November 12, 2009

Alert Level: **INFORMATIONAL**

Instrument: RAS and PPS Samplers

Software Versions: N/A

Subject: Water Flush Filters

Summary: Use a 5.0 μ m, 25mm filter on the water flush filter for RAS and PPS samplers to produce optimum results and protect the gears and the pump.

Technical Details: McLane installs the Millipore Isopore 5.0 μ m, 25mm filter (model TMTP 025 00) on the water flush filter for RAS and PPS samplers. Several extra filters are supplied in the toolkit.