

Technical Support Bulletin 2024-01	L24-1000 and L12-1733 Revised Specifications	Feb 13, 2024
---	---	---------------------

Alert Level: INFORMATIONAL

Instruments: MMP, ITP

Software Versions: N/A

Hardware Version: N/A

Subject: Manufacturer's Revisions to Lithium Battery Pack Specifications

Summary: Electrochem, manufacturer of L24-1000 and L12-1733 battery packs, has revised the specifications for their 3B0036 battery cells. This higher current is much greater than MMP or ITP operating currents use.

The specifications changed because the manufacturer now tests at a higher current to standardize testing procedures and cell ratings.

Note - The battery chemistry and battery construction have not changed. The actual battery capacity also has not changed, only the rated capacity. The battery estimates in Deployment Planner should remain at the default 240 and 120 Ah.

Revised Specifications

	L24-1000	L12-1733
NEW	208 Ah	104 Ah
OLD	240 Ah	120 Ah